


# Panamax MIW Connection Diagram


NOTE: This is not intended as a substitute for professional system design. Consult an authorized Panamax dealer to determine your power protection needs in compliance with local building codes.

LEGEND	
LAN Cables	— — — — —
Phone cables	.....
Coaxial cables	
12V Trigger Lines	~~~~~
Electrical Cords	—————

1. Route component communication cables (LAN, telephone). Do not plug in the MIW unit. See tech brief for details.



2. Connect component signal line cables (coaxial and 12V trigger). See tech brief for details.



3. Connect component electrical cords to outlets. See tech brief for details.

